



*Make your space,  
a healthy place.*

OUR  
COMMON  
FUTURE

## **FOREVERBREATHE OILED INTERNAL TIMBER CARE AND MAINTENANCE**

### Initial Floor Care:

Treat all new floor surfaces with great care as they continue to harden for up to 4 weeks. Correctly applied, Java High Solid Oil will cure to good strength after a period of 10-14 days, avoid water contact and do not wet mop before this time. The surface will continue to harden for up to 28 days. It's advisable to take extra care throughout this time & use felt pads under your furniture etc.

### General Cleaning:

Use the Foreverbreathe Microclean for your weekly or regular cleaning. Add 1 cap full (approx. 10ml) of the Foreverbreathe Microclean to a 1l of water in a handy spray bottle. Shake well before use. Mist spray the solution over the surface to be cleaned. Wipe back using a microfiber pad or cloth. Leave to dry.

### Nourish & Replenish:

Use the Foreverbreathe Microwax with a 50/50 solution of water to rejuvenate your floor. Use a handy spray bottle. Shake well before use, mist spray the solution over the floor. Mop or wipe back using a microfibre mop, leave to dry.

### Manage:

For stubborn marks and surface scratching use undiluted Foreverbreathe Microwax lightly burnished in the direction of the grain using a green 3M hand scourer available at supermarkets. Polish dry with a cotton cloth.

**TO REORDER Microwax & Microclean, please visit our ONLINE STORE  
[www.healthbasedbuilding.com](http://www.healthbasedbuilding.com)**