

Technical Document	#018
Product	Paint Guide Resene
Issue	12-07-2022
Version	1.8



the paint the professionals use



the paint the professionals use

Resene Paint System approved for application to Magnum Board

Interior

Prep: Wipe the board surface down with a damp cloth or sponge to remove surface dust and allow to dry.

Adhesion Primer - Resene Stone Strengthener

https://www.resene.com/products/Downloads/Stone_Strengthener.htm

Cut in using a 50mm Legend cutting-in brush, paint 40mm to 50mm out from the edges.

Using a Resene No 5-roller sleeve apply a thin even coat to the wall surface minimising overlap onto edge areas of cutting in.

Leave to cure with ventilation for 48 hours.

Undercoat Resene Quick Dry Primer Undercoat <https://www.resene.co.nz/archspec/datasheets/d45-QuickDryPrimerUndercoat.pdf>

Once the adhesion primer is fully cured apply a full coat of Resene Quick Dry Primer Undercoat using a Resene No 7-roller sleeve or spray equipment with appropriate settings.

Topcoat Interior Resene Spacecote Low Sheen or Spacecote Low Sheen Kitchen and Bathroom

<https://shop.resene.co.nz/spacecote-low-sheen> <https://shop.resene.co.nz/zylone-sheen>

Apply 2 coats of topcoat colour using a Resene No 7-roller sleeve or spray equipment with appropriate settings

Exterior

Prep: Wipe the board surface down with a damp cloth or sponge to remove surface dust and allow to dry.

Adhesion Primer - Resene Stone Strengthener

https://www.resene.com/products/Downloads/Stone_Strengthener.htm

Cut in using a 50mm Legend cutting-in brush, paint 40mm to 50mm out from the edges.

Using a Resene No 5-roller sleeve apply a thin even coat to the wall surface minimising overlap onto edge areas of cutting in.

Leave to cure with ventilation for 48 hours.

Undercoat Resene Quick Dry Primer Undercoat <https://www.resene.co.nz/archspec/datasheets/d45-QuickDryPrimerUndercoat.pdf>

Once the adhesion primer is fully cured apply a full coat of Resene Quick Dry Primer Undercoat using a Resene No 7-roller sleeve or spray equipment with appropriate settings.

Topcoat Resene X-200, Lumbersider, or Sonyx <https://shop.resene.co.nz/resene-lumbersider>

<https://shop.resene.co.nz/resene-sonyx-101>

Apply 2 x coats using a No 7-roller sleeve or spray equipment with appropriate settings.

Ceilings

Prep: Wipe the board surface down with a damp cloth or sponge to remove surface dust and allow to dry.

Adhesion Primer - Resene Stone Strengthener

https://www.resene.com/products/Downloads/Stone_Strengthener.htm

Cut in using a 50mm Legend cutting-in brush, paint 40mm to 50mm out from the edges.

Using a Resene No 5-roller sleeve apply a thin even coat to the wall surface minimising overlap onto edge areas of cutting in.

Leave to cure with ventilation for 48 hours.

Undercoat Resene Quick Dry Primer Undercoat <https://www.resene.co.nz/archspec/datasheets/d45-QuickDryPrimerUndercoat.pdf>

Once the adhesion primer is fully cured apply a full coat of Resene Quick Dry Primer Undercoat using a Resene No 7-roller sleeve or spray equipment with appropriate settings.

Resene Ceiling Paint <https://shop.resene.co.nz/ceiling-paint>

Apply 2 coats of topcoat colour using a Resene No 7-roller sleeve or spray equipment with appropriate settings

Note:

Unless stated otherwise, all products to be applied in accordance with the relevant Resene Product Data Sheet.